



AUXILIARY HYDRAULIC KITS for EXCAVATORS

# PREMIUM JOYSTICK with MONITOR CONTROL OPTIONS



**HCT Premium Joystick**

Kits can integrate seamlessly with factory joystick and onboard OEM Monitor for Flow Setting, Function Select, and 2-pump flow. Pressure select options are available on select machines.



### J1-R/H JOYSTICK Proportional Application

- Used for R/H Operation
- Slider Proportional (requires external driver)
- 3 Pushbuttons (non proportional)
- 1 Trigger
- Recommended for: SHEAR/DUAL PURPOSE KITS/THUMB

**A-0155-01**



### J2-L/H JOYSTICK Proportional Application

- Used for L/H Operation
- Slider Proportional (requires external driver)
- 3 Pushbuttons (non proportional)
- 1 Trigger
- Recommended for: ROTATION

**A-0156-01**



### J4-L/H or R/H JOYSTICK Non Proportional Application

- Used for R/H or L/H Operation
- 4 Pushbuttons (non proportional)
- 1 Trigger
- Recommended for: BREAKER/SHEAR/THUMB/ROTATION

**MATCHING  
L/H  
JOYSTICK  
AVAILABLE**

